

Over The Radiator Cold Air Intake Installation instruction



1. Wait until your engine has cooled completely then Remove the stock air intake.



2. Inseart the new intake into the intake slot.



3. Put on the hose that connect OTR to the engine.



4. Put on the clamps on both the OTR side and the engine side.



5. Secure hose clamps on both side.



6. Connect the Airflow meter wire to the socket.



7. Enjoy the power boost !