

VE Commodore Strut Brace Install



1. Fit spacers to the 2 holes in strut towers.



2. Sit strut brace ends in position and drill the 3 bolt holes – note large type spacers for inner bolt hole



3. Fit strut brace ends with bolts and spacers from inside wheel arch and lightly tighten.



4. Fit strut brace to end plates making sure that the bar is adjusted to correct length.



5. Tighten all bolts

